

# DataLogic Magellan 1000i и 1100i




Standard Product Default Settings



ENABLE TRANSMISSION OF CONTROL CHARACTERS



START/END PROGRAMMING BARCODES



0



START/END PROGRAMMING BARCODES




START/END PROGRAMMING BARCODES




START/END PROGRAMMING BARCODES



SET PREFIX



2



START/END PROGRAMMING BARCODES